


TSM2500 and TSM1500 Connections

Red - Positive DC Out
Black - Negative DC Out



SB50 Connector

Note: CAN Signal wires above are only used for CAN enabled chargers. Not used with the 48v "Non-CAN" charger.

For 110V




Yellow/Green - Ground Wire
Blue - Neutral Wire
Brown - Live Wire

For 220V



Yellow/Green - Ground Wire
Blue - Live Wire
Brown - Live Wire



Optional Charger 12v Output Connector
 - later models only



Charge Indicator Connector

Note: Other connectors in the charger harness are non-essential and may remain disconnected